




Substation Control Cable

Substation Control Cables are used in various industrial and utility applications such as transformers, relays, and outdoor substation monitoring equipment to transmit low voltage signals. They can be installed in open air, in ducts or conduits, in trays or troughs and direct burial applications. Substation Control Cables are for circuits up to 600 volts and temperatures up to 75°C.

RoHS compliant • REACH compliant • PVC Jacket • Heat, moisture, & sunlight resistant

Shielded



- 18 AWG - 15/10 PE/PVC
- 14 AWG - 20/10 PE/PVC
- 12 AWG - 20/10 PE/PVC
- 10 AWG - 20/10 PE/PVC
- 18 AWG - 30/15 PE/PVC
- 14 AWG - 30/15 PE/PVC
- 12 AWG - 30/15 PE/PVC
- 10 AWG - 30/15 PE/PVC
- 6 AWG - 30/15 PE/PVC
- 8 AWG - 45/15 PE/PVC
- 6 AWG - 45/25 PE/PVC
- 4 AWG - 45/25 PE/PVC
- 4 AWG - 45/30 PE/PVC
- 2 AWG - 45/30 PE/PVC

Unshielded



- 18 AWG - 15/10 PE/PVC
- 14 AWG - 20/10 PE/PVC
- 12 AWG - 20/10 PE/PVC
- 10 AWG - 20/10 PE/PVC
- 18 AWG - 30/15 PE/PVC
- 14 AWG - 30/15 PE/PVC
- 12 AWG - 30/15 PE/PVC
- 10 AWG - 30/15 PE/PVC
- 6 AWG - 30/15 PE/PVC
- 8 AWG - 45/15 PE/PVC
- 6 AWG - 45/25 PE/PVC
- 4 AWG - 45/25 PE/PVC
- 4 AWG - 45/30 PE/PVC
- 2 AWG - 45/30 PE/PVC



See the Complete Spec Sheets



PRIORITY
WIRE & CABLE, INC.

When **TIME** and **EFFICIENCY**
are just as important as **PRICE** and **QUALITY** . . .

We make your business our **PRIORITY**

Millions of Square Feet of Warehouse



Hundreds of Millions of Dollars in Inventory

Your Inside Contact is: _____
_____ @prioritywire.com

US: 1-800-945-5542 • CANADA: 1-877-611-5122

WWW.PRIORITYWIRE.COM